

How to upload the  
firmware version

**ONE-500**

Support handbook



**LDA**  
**audioTech**

one



## 1. Introduction

This document details how to upload the firmware version in ONE-500 for LDA PA/VA systems.

## 2. Upload firmware version


### 2.1. DOWLOAD THE FILE

First step, go to LDA support website and download the last firmware version for ONE-500, and load in the main root of your USB pen drive.

<http://support.lda-audiotech.com/en/software>

### 2.2. LOAD THE FILE

Insert the pen drive in the USB socket (a) at NEO-500:



Go to CONFIG menu and to LOAD SAVE / FW UPDATE (access level 3).

---

Please contact with LDA Support Department for any information

[support@lda-audiotech.com](mailto:support@lda-audiotech.com)